### GenJet™ In Vitro DNA Transfection Reagent for MDCK Cells (Ver. II)

---- A Protocol for Transfecting MDCK Cells

€	Signa ( Laborate	Gen
$\mathcal{L}$	Laborato	ories

10075 Tyler Place, Suite 19 Ijamsville, MD 21754 FAX. 301-560-4919 TEL. 301-330-5966

Toll Free. 1-(866)-918-6812 Email: <u>info@signagen.com</u> Web: <u>www.signagen.com</u>



This product is for laboratory research ONLY and not for diagnostic use

### Introduction:

GenJet™ In Vitro DNA Tranfection Reagent (Ver. II) is upgraded version of GenJet™ In Vitro DNA Tranfection Reagent. With a new chemistry, more DNA condensing groups were released in the new version compared with old version GenJet™, leading to 3~20 times more efficient in DNA delivery. GenJet™ (Ver. II) for MDCK cells was pre-optimized and conditioned for transfecting MDCK cells.

# Procedures for Transfecting MDCK Cells: Step I. Culturing of Cells Before Transfection

Cells should be plated at least 24 hours prior to transfection so that the monolayer cell density reaches to the optimal  $95\sim100\%$  confluency at the day of transfection.

Table 1. A Guideline for Optimal Cell Number Per Well in Different Culture Formats

Culture Dishes	Surface Area (cm²)	Optimal Cell Number
T75 Flask	75	9.6 x 10 <sup>6</sup>
100 mm Dish	58	7.3 x 10 <sup>6</sup>
60 mm Dish	21	2.7 x 10 <sup>6</sup>
35 mm Dish	9.6	1.2 x 10 <sup>6</sup>
6-well Plate	9.6	1.2 x 10 <sup>6</sup>
12-well Plate	3.5	0.44 x 10 <sup>6</sup>
24-well Plate	1.9	0.24 x 10 <sup>6</sup>
48-well Plate	1.0	0.11 x 10 <sup>6</sup>
96-well Plate	0.3	0.31 x 10 <sup>5</sup>

**Table 2. Recommended Amounts for Different Culture Vessel Formats** 

Culture Dish	Transfection Complex Volume (ml)	Plasmid DNA (μg)	GenJet™ Reagent (μL)
96-well	0.02	0.2	0.8
48-well	0.04	0.5	2
24-well	0.1	1.0	4
6-well	0.2	2	8
35 mm dish	0.2	2	8
60 mm dish	0.5	5	20
10 cm dish	1.0	8	32
T75 flask	1.5	36	144
250 ml flask	2.5	100	400

#### Step II. Preparation of Cells in Suspension

The following protocol is given for transfecting MDCK in 6-well plates, refer to **Table 1** for optimal cell number per well per culture vessels' surface area. The optimal transfection conditions for MDCK cells are given in the standard protocol described below.

- Detach the MDCK cells with trypsin/EDTA and stop the trypsinization with complete culture medium.

**Note:** Cells that are difficult to detach may be placed at 37 °C for 5-15 min to facilitate detachment

- Take an aliquot of trypsinized cell suspension and count the cells to determine the cell density.
- Centrifuge the required 1.2x10<sup>6</sup> cells per well for 6-well plate at 150xg at room temperature for 10 min.
- Use fine tip pipette to remove supernatant **completely** so that no residual medium covers the cell pellet.

## Step III. Preparation and application of Transfection Complex

For MDCK cells, the optimal ratio of GenJet™ (μL):DNA (μg) is 4:1. To ensure the optimal size of complex particles, we recommend using serum-free DMEM with High Glucose to dilute DNA and GenJet™ Reagent.

The following protocol is given for transfection in 6-well plates, refer to **Table 2** for transfection in other culture formats.

- For each well of 6-well plate, dilute 2  $\mu g$  of DNA into 100  $\mu l$  of serum-free DMEM with High Glucose. Immediately pipette up and down to mix.
- For each well of 6-well plate, dilute 8 μl of GenJet™ reagent (Ver. II) into 100 μl of serum-free DMEM with High Glucose. Immediately pipette up and down to mix.

Note: Never use Opti-MEM to dilute GenJet™ reagent and DNA, it will disrupt transfection complex.

- Add the diluted GenJet™ Reagent immediately to the diluted DNA solution all at once. (Important: do not mix the solutions in the reverse order!)
- Immediately pipette up and down 3~4 times or vortex briefly to mix followed by incubation for ~15 minutes at room temperature to allow GenJet™-DNA transfection complexes to form.

**Note:** Never keep the transfection complexes longer than 20 minutes

- Resuspend the cell pellet prepared from **Step II** immediately in the 200  $\mu$ l transfection complex and incubate at 37 °C for 20 minutes.
- At the end of incubation, add 2.0 ml of pre-warmed fresh complete cell growth medium to cells and plate onto one well of a 6-well plate.
- Check transfection efficiency 24 to 48 hours post transfection.